

Configuring digital I/O with MATLAB® Data Acquisition Toolbox

These instructions explain how to set the direction of digital ports and bits from a Measurement Computing (MCC) data acquisition device using MATLAB Data Acquisition Toolbox*. The Measurement Computing brand miniLAB 1008 is used in this example.

**This example was tested with MATLAB version 7.*

1. Run *InstaCal* and note the board number assigned to the miniLAB 1008.


In this example, the miniLAB 1008 is assigned Board# 0.

Perform the following steps to control the miniLAB 1008 device's digital ports.

2. Run MATLAB and enter `dio = digitalio ('mcc',0)` at the `>>` prompt in the **Command Window**.

This command creates a DIO object using board# 0 — the miniLAB 1008 — as an MCC-type device in MATLAB.

After you enter this command, the screen updates with miniLAB 1008 device information:



```

Command Window

>> dio = digitalio ('mcc',0)

Display Summary of DigitalIO (DIO) Object Using 'miniLAB 1008'.

      Port Parameters:  Port 0 is line configurable for reading and writing.
                        Port 1 is port configurable for reading and writing.
                        Port 2 is port configurable for reading and writing.
                        Port 3 is port configurable for reading and writing.
                        Port 4 is port configurable for reading and writing.

      Engine status:   Engine not required.

DIO object contains no lines.

>>
  
```

3. At the `>>` command prompt, enter `addline(dio,4:27, 'out')`. The Command Window updates with the port information.

This command adds digital I/O lines and configures them for output ('out').

The `addline` method is zero-based — a device with 28 bits is written as 0 to 27. The miniLAB 1008 has 28 digital I/O lines: four DIO channels are on the top screw terminals (channels 0 to 3), and 24 DIO channels are on the 37-pin D connector (channels 4 to 27).

Command Window

```
>> addline(dio,4:27,'out')
```

Index:	LineName:	HwLine:	Port:	Direction:
1	''	0	1	'Out'
2	''	1	1	'Out'
3	''	2	1	'Out'
4	''	3	1	'Out'
5	''	4	1	'Out'
6	''	5	1	'Out'
7	''	6	1	'Out'
8	''	7	1	'Out'
9	''	0	2	'Out'
10	''	1	2	'Out'
11	''	2	2	'Out'
12	''	3	2	'Out'
13	''	4	2	'Out'
14	''	5	2	'Out'
15	''	6	2	'Out'
16	''	7	2	'Out'
17	''	0	3	'Out'
18	''	1	3	'Out'
19	''	2	3	'Out'
20	''	3	3	'Out'
21	''	0	4	'Out'
22	''	1	4	'Out'
23	''	2	4	'Out'
24	''	3	4	'Out'

On this window, indices 1 to 8 are FirstPortA, indices 9 to 16 are FirstPortB, indices 17 to 20 are FirstPortCL, and indices 21 to 24 are FirstPortCH.

4. Use the `putvalue` command to set the logic state of a bit, port, or any number of bits you choose to control.

The example commands below control FirstPortA, bit 0.

The `putvalue` command is one-based — a device with 28 bits is written as 1 to 28.

- To turn FirstPortA bit 0 *on*, enter, `putvalue(dio.line(1),1)`.

FirstPortA bit 0 is index number 1.

- To turn FirstPortA bit 0 *off*, enter `putvalue(dio.line(1),0)`.
- To turn all 8 bits contained in FirstPortA *on*, enter `putvalue(dio.line(1:8), 255)`.
- To turn all 8 bits contained in FirstPortA *off*, enter `putvalue(dio.line(1:8), 0)`.

You control the other ports in the same manner.

- To control the individual bits contained in FirstPortB, but still update the entire port at once, enter `putvalue(dio.line(9:16),logical([111000101]))`

Remember, indices 9 to 16 are FirstPortB.

5. When you are done controlling the digital channels, enter the following commands at the `>>` prompt to remove the DIO object from memory and from the MATLAB workspace.

- `delete(dio);`
- `clear('dio');`

The full MATLAB **Command Window** display is shown here.

Command Window

```
>> dio = digitalio ('mcc',0)
```

Display Summary of DigitalIO (DIO) Object Using 'miniLAB 1008'.

Port Parameters: Port 0 is line configurable for reading and writing.
 Port 1 is port configurable for reading and writing.
 Port 2 is port configurable for reading and writing.
 Port 3 is port configurable for reading and writing.
 Port 4 is port configurable for reading and writing.

Engine status: Engine not required.

DIO object contains no lines.

```
>> addline(dio,4:27,'out')
```

Index:	LineName:	HvLine:	Port:	Direction:
1	''	0	1	'Out'
2	''	1	1	'Out'
3	''	2	1	'Out'
4	''	3	1	'Out'
5	''	4	1	'Out'
6	''	5	1	'Out'
7	''	6	1	'Out'
8	''	7	1	'Out'
9	''	0	2	'Out'
10	''	1	2	'Out'
11	''	2	2	'Out'
12	''	3	2	'Out'
13	''	4	2	'Out'
14	''	5	2	'Out'
15	''	6	2	'Out'
16	''	7	2	'Out'
17	''	0	3	'Out'
18	''	1	3	'Out'
19	''	2	3	'Out'
20	''	3	3	'Out'
21	''	0	4	'Out'
22	''	1	4	'Out'
23	''	2	4	'Out'
24	''	3	4	'Out'

```
>> putvalue(dio.line(1),1)
```

```
>> putvalue(dio.line(1),0)
```

```
>> putvalue(dio.line(1:8),255)
```

```
>> putvalue(dio.line(1:8),0)
```

```
>> putvalue(dio.line(9:16),logical([1 1 1 0 0 1 0 1]))
```

```
>> delete(dio);
```

```
>> clear('dio');
```

For more information on digital I/O operations with the MATLAB Data Acquisition Toolbox, refer to Chapter 7 of the *Data Acquisition Toolbox User's Guide (Version 2)* at

www.mathworks.com/access/helpdesk/help/pdf_doc/daq/daqug.pdf.